

R34 - 1,000 km (600 Miles) Service

Engine and Emission Control Maintenance

Inspect and correct or replace as necessary:

- ☐ engine oil level
- ☐ engine coolant level
- ☐ brake fluid level
- ☐ windshield washer fluid level
- ☐ battery fluid level
- ☐ idle RPM
- ☐ drive belts.

Chassis and Body Maintenance

Inspect and correct or replace as necessary:

- ☐ steering gear and linkage
- ☐ axle
- ☐ suspension parts
- ☐ prop shaft
- ☐ drive shafts

Information derived from R34 Nissan Skyline Owners Manual (Nissan Japan) and R34 Nissan Skyline Vehicle Warranty and Owners Identification Manual (Nissan New Zealand)

R34 - 10,000 km (6,000 Miles)/6 Months Service

Engine and Emission Control Maintenance

Replace:

- ☐ engine oil
- ☐ engine oil filter.

Chassis and Body Maintenance

Inspect and correct or replace as necessary:

- ☐ brake, clutch and auto transmission fluid levels and for leakage
- ☐ power steering fluid levels and lines for leakage
- ☐ braking systems
- ☐ clutch system
- ☐ exhaust system
- ☐ manual transmission, front and rear differentials and transfer case oils for levels and leakage
- ☐ brake pads, discs and associated brake components
- ☐ foot brake, park brake and clutch for free play, stroke and operation.

Lubricate:

- ☐ locks, hinges and bonnet/boot latches.

R34 - 20,000 km (12,000 Miles)/12 Months Service

Engine and Emission Control Maintenance

Replace:

- ☐ engine oil
- ☐ engine oil filter.
- ☐

Inspect and correct or replace as necessary:

- ☐ valve clearances if there is an increase in valve noise
- ☐ engine cooling system.

Chassis and Body Maintenance

Replace:

- ☐ ventilation air filter.

Inspect and correct or replace as necessary:

- ☐ brake, clutch and auto transmission fluid levels and for leakage
- ☐ power steering fluid levels and lines for leakage
- ☐ braking systems
- ☐ clutch system
- ☐ exhaust system
- ☐ manual transmission, front and rear differentials and transfer case oils for levels and leakage
- ☐ steering gear and linkage
- ☐ axle
- ☐ suspension parts
- ☐ prop shaft
- ☐ drive shafts
- ☐ wheel alignment, rotation and balance of wheels
- ☐ brake pads, discs and associated brake components
- ☐ foot brake, park brake and clutch for free play, stroke and operation.
- ☐ seat belt, buckles, retractors, anchors and adjuster

Lubricate:

- ☐ locks, hinges and bonnet/boot latches.

R34 - 30,000 km (18,000 Miles)/18 Months Service

Engine and Emission Control Maintenance

Replace:

- ☐ engine oil
- ☐ engine oil filter.

Chassis and Body Maintenance

Inspect and correct or replace as necessary:

- ☐ brake, clutch and auto transmission fluid levels and for leakage
- ☐ power steering fluid levels and lines for leakage
- ☐ braking systems
- ☐ clutch system
- ☐ exhaust system
- ☐ manual transmission, front and rear differentials and transfer case oils for levels and leakage
- ☐ brake pads, discs and associated brake components
- ☐ foot brake, park brake and clutch for free play, stroke and operation.

Lubricate:

- ☐ locks, hinges and bonnet/boot latches.

R34 - 40,000 km (24,000 Miles)/24 Months Service

Engine and Emission Control Maintenance

Replace:

- ☐ engine oil
- ☐ engine oil filter.

Inspect and correct or replace as necessary:

- ☐ valve clearances if there is an increase in valve noise
- ☐ drive belts
- ☐ engine coolant mixture ratio
- ☐ cooling system
- ☐ fuel lines
- ☐ EVAP vapour lines
- ☐ heated oxygen sensor.

Chassis and Body Maintenance

Replace:

- ☐ brake fluid
- ☐ front and rear differentials and transfer case oils
- ☐ ventilation air filter.

Inspect and correct or replace as necessary:

- ☐ brake, clutch and auto transmission fluid levels and for leakage
- ☐ brake booster vacuum hoses, connections and check valve
- ☐ power steering fluid levels and lines for leakage
- ☐ braking systems
- ☐ clutch system
- ☐ exhaust system
- ☐ manual transmission gear oil for levels and leakage
- ☐ steering gear and linkage
- ☐ axle
- ☐ suspension parts
- ☐ prop shaft
- ☐ drive shafts
- ☐ wheel alignment, rotation and balance of wheels
- ☐ brake pads, discs and associated brake components
- ☐ foot brake, park brake and clutch for free play, stroke and operation.
- ☐ seat belt, buckles, retractors, anchors and adjuster

Lubricate:

- ☐ locks, hinges and bonnet/boot latches.

R34 - 50,000 km (30,000 Miles)/30 Months Service

Engine and Emission Control Maintenance

Replace:

- ☐ engine oil
- ☐ engine oil filter
- ☐ air cleaner filter (viscous type)
- ☐ fuel filter.

Chassis and Body Maintenance

Inspect and correct or replace as necessary:

- ☐ brake, clutch and auto transmission fluid levels and for leakage
- ☐ power steering fluid levels and lines for leakage
- ☐ braking systems
- ☐ clutch system
- ☐ exhaust system
- ☐ manual transmission, front and rear differentials and transfer case oils for levels and leakage
- ☐ brake pads, discs and associated brake components
- ☐ foot brake, park brake and clutch for free play, stroke and operation.

Lubricate:

- ☐ locks, hinges and bonnet/boot latches.

R34 - 60,000 km (36,000 Miles)/36 Months Service

Engine and Emission Control Maintenance

Replace:

- engine oil
- engine oil filter.

Inspect and correct or replace as necessary:

- ☐ valve clearances if there is an increase in valve noise
- ☐ engine cooling system.

Chassis and Body Maintenance

Replace:

- ☐ ventilation air filter.

Inspect and correct or replace as necessary:

- ☐ brake, clutch and auto transmission fluid levels and for leakage
- ☐ power steering fluid levels and lines for leakage
- ☐ braking systems
- ☐ clutch system
- ☐ exhaust system
- ☐ manual transmission, front and rear differentials and transfer case oils for levels and leakage
- ☐ steering gear and linkage
- ☐ axle
- ☐ suspension parts
- ☐ prop shaft
- ☐ drive shafts
- ☐ wheel alignment, rotation and balance of wheels
- ☐ brake pads, discs and associated brake components
- ☐ foot brake, park brake and clutch for free play, stroke and operation.
- ☐ seat belt, buckles, retractors, anchors and adjuster

Lubricate:

- ☐ locks, hinges and bonnet/boot latches.

R34 - 70,000 km (42,000 Miles)/42 Months Service

Engine and Emission Control Maintenance

Replace:

- ☐ engine oil
- ☐ engine oil filter.

Chassis and Body Maintenance

Inspect and correct or replace as necessary:

- ☐ brake, clutch and auto transmission fluid levels and for leakage
- ☐ power steering fluid levels and lines for leakage
- ☐ braking systems
- ☐ clutch system
- ☐ exhaust system
- ☐ manual transmission, front and rear differentials and transfer case oils for levels and leakage
- ☐ brake pads, discs and associated brake components
- ☐ foot brake, park brake and clutch for free play, stroke and operation.

Lubricate:

- ☐ locks, hinges and bonnet/boot latches.

R34 - 80,000 km (48,000 Miles)/48 Months Service

Engine and Emission Control Maintenance

Replace:

- ☐ engine oil
- ☐ engine oil filter
- ☐ engine coolant.

Inspect and correct or replace as necessary:

- ☐ valve clearances if there is an increase in valve noise
- ☐ drive belts
- ☐ cooling system
- ☐ fuel lines
- ☐ EVAP vapour lines
- ☐ heated oxygen sensor.

Chassis and Body Maintenance

Replace:

- ☐ brake fluid
- ☐ front and rear differentials and transfer case oils
- ☐ ventilation air filter.

Inspect and correct or replace as necessary:

- ☐ brake, clutch and auto transmission fluid levels and for leakage
- ☐ brake booster vacuum hoses, connections and check valve
- ☐ power steering fluid levels and lines for leakage
- ☐ braking systems
- ☐ clutch system
- ☐ exhaust system
- ☐ manual transmission gear oil for levels and leakage
- ☐ steering gear and linkage
- ☐ axle
- ☐ suspension parts
- ☐ prop shaft
- ☐ drive shafts
- ☐ wheel alignment, rotation and balance of wheels
- ☐ brake pads, discs and associated brake components
- ☐ foot brake, park brake and clutch for free play, stroke and operation.
- ☐ seat belt, buckles, retractors, anchors and adjuster

Lubricate:

- ☐ locks, hinges and bonnet/boot latches.

R34 - 90,000 km (54,000 Miles)/54 Months Service

Engine and Emission Control Maintenance

Replace:

- ☐ engine oil
- ☐ engine oil filter.

Chassis and Body Maintenance

Inspect and correct or replace as necessary:

- ☐ brake, clutch and auto transmission fluid levels and for leakage
- ☐ power steering fluid levels and lines for leakage
- ☐ braking systems
- ☐ clutch system
- ☐ exhaust system
- ☐ manual transmission, front and rear differentials and transfer case oils for levels and leakage
- ☐ brake pads, discs and associated brake components
- ☐ foot brake, park brake and clutch for free play, stroke and operation.

Lubricate:

- ☐ locks, hinges and bonnet/boot latches.

R34 - 100,000 km (60,000 Miles)/60 Months Service

Engine and Emission Control Maintenance

Replace:

- ☐ engine oil
- ☐ engine oil filter
- ☐ air cleaner filter (viscous type)
- ☐ fuel filter
- ☐ spark plugs (platinum type)
- ☐ timing belt.

Inspect and correct or replace as necessary:

- ☐ valve clearances if there is an increase in valve noise
- ☐ engine cooling system.

Chassis and Body Maintenance

Replace:

- ☐ ventilation air filter
- ☐ manual transmission oil.

Inspect and correct or replace as necessary:

- ☐ brake, clutch and auto transmission fluid levels and for leakage
- ☐ power steering fluid levels and lines for leakage
- ☐ braking systems
- ☐ clutch system
- ☐ exhaust system
- ☐ manual transmission, front and rear differentials and transfer case oils for levels and leakage
- ☐ steering gear and linkage
- ☐ axle
- ☐ suspension parts
- ☐ prop shaft
- ☐ drive shafts
- ☐ wheel alignment, rotation and balance of wheels
- ☐ brake pads, discs and associated brake components
- ☐ foot brake, park brake and clutch for free play, stroke and operation.
- ☐ seat belt, buckles, retractors, anchors and adjuster

Lubricate:

- ☐ locks, hinges and bonnet/boot latches.

R34 Severe Conditions

The maintenance schedules listed here do not take into account driving under severe conditions. Nissan considers the following conditions as severe:

- ☐ driving under dusty conditions
- ☐ driving repeatedly short distances
- ☐ towing a trailer or caravan
- ☐ extensive idling
- ☐ driving in extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high
- ☐ driving in high humidity areas or in mountainous areas
- ☐ driving in areas using salt or other corrosive materials
- ☐ driving on rough and/or muddy roads or in the desert
- ☐ driving with frequent use of braking or in mountainous areas

Driving under dusty conditions

- ☐ replace engine oil more frequently
- ☐ replace oil filter every 5,000 km (3,000 Miles)
- ☐ replace air cleaner filter every 20,000 km (12,000 Miles) or 12 months
- ☐ replace fuel filter every 20,000 km (12,000 Miles) or 12 months
- ☐ check brake pads, discs and brake components every 5,000 km (3,000 Miles) or 3 months
- ☐ replace ventilation air filter more frequently

Driving repeatedly short distances

- ☐ replace engine oil more frequently
- ☐ replace oil filter every 5,000 km (3,000 Miles)

Towing a trailer or caravan

- ☐ replace engine oil more frequently
- ☐ replace oil filter every 5,000 km (3,000 Miles)
- ☐ replace automatic transmission oil every 40,000 km (24,000 Miles) or 24 months
- ☐ replace limited slip differential gear oil every 20,000 km (12,000 Miles) or 12 months
- ☐ check brake pads, discs and brake components every 5,000 km (3,000 Miles) or 3 months
- ☐ check propeller and drive shafts every 10,000 km (6,000 Miles) or 6 months

Extensive idling

- ☐ replace engine oil more frequently
- ☐ replace oil filter every 5,000 km (3,000 Miles)

Driving in extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high

- ☐ replace fuel filter every 20,000 km (12,000 Miles) or 12 months

Driving in high humidity areas or in mountainous areas

- ☐ replace brake fluid every 20,000 km (12,000 Miles) or 12 months

Driving in areas using salt or other corrosive materials

- ☐ check brake pads, discs and brake components every 5,000 km (3,000 Miles) or 3 months
- ☐ check steering gear and linkage, axle and suspension parts, and exhaust system every 10,000 km (6,000 Miles) or 6 months
- ☐ lubricate locks, hinges and bonnet/boot latches every 5,000 km (3,000 Miles) or 3 months

Driving on rough and/or muddy roads or in the desert

- ☐ check steering gear and linkage, axle and suspension parts, and exhaust system every 10,000 km (6,000 Miles) or 6 months
- ☐ replace automatic transmission oil every 40,000 km (24,000 Miles) or 24 months
- ☐ replace limited slip differential gear oil every 40,000 km (24,000 Miles) or 24 months
- ☐ check brake pads, discs and brake components every 5,000 km (3,000 Miles) or 3 months
- ☐ check propeller and drive shafts every 10,000 km (6,000 Miles) or 6 months

Driving with frequent use of braking or in mountainous areas

- ☐ check brake pads, discs and brake components every 5,000 km (3,000 Miles) or 3 months