

## Nissan 1990-1995 300ZX, 92-94 Maxima VE30DE

ECU Pinout Diagram

101 102 103 104 105 106 107 108	1 2 3 4 5 6 7 8 9 10 21222324252627282930 41 424344454647484950
109 110 111 112 113 114 115 116	11 12 13 14 15 16 17 18 19 20 31 32 33 34 35 36 37 38 39 40 51 52 53 54 55 56 57 58 59 60

Pin #	Name	Function	Signal Type
7	Tachometer Signal	Engine Speed Sensor Signal	Speed
10	Power Ground (Engine Control Module)	Chassis Ground	Ground
20	Power Ground (Engine Control Module)	Chassis Ground	Ground
23	Knock Sensor	Knock Sensor Signal	Knock, Audio
26	Mass Air Flow Sensor Ground	Chassis Ground	Ground
27	Mass Air Flow Sensor	Mass Air Flow Sensor Signal	Analog
28	Engine Coolant Temperature Sensor	Engine Coolant Temperature Sensor Signal	Analog
29	O2 Sensor Signal (Right side)	Oxygen Sensor Signal (Right side)	Analog
30	Sensor Ground	Chassis Ground	Ground
38	Throttle Position Sensor	Throttle Position Sensor Signal	Analog
45	Ignition Switch	12V Switched	Power
49	Power Supply (Engine Control Module)	12V Switched	Power
50	Power Ground (Engine Control Module)	Chassis Ground	Ground
53	Vehicle Speed Sensor	Vehicle Speed Sensor Signal	Speed
58	Power Supply (Aux)	12V Permanent	Power
59	Power Supply (Engine Control Module)	12V Switched	Power
60	Power Ground (Engine Control Module)	Chassis Ground	Ground
101	Injector # 1	Engine Speed Sensor Signal (Injector # 1)	Speed
103	Injector # 3	Engine Speed Sensor Signal (Injector # 3)	Speed
105	Injector # 5	Engine Speed Sensor Signal (Injector # 5)	Speed
107	Power Ground (Engine Control Module)	Chassis Ground	Ground
108	Power Ground (Engine Control Module)	Chassis Ground	Ground
109	Power Supply (Engine Control Module)	12V Switched	Power
110	Injector # 2	Engine Speed Sensor Signal (Injector # 2)	Speed
112	Injector # 4	Engine Speed Sensor Signal (Injector # 4)	Speed
114	Injector # 6	Engine Speed Sensor Signal (Injector # 6)	Speed
116	Power Ground (Engine Control Module)	Chassis Ground	Ground



## Caution!

If you are not familiar with the vehicle's electrical systems, onboard sensors, and vehicle dynamics, DO NOT attempt to perform ANY installation of PLX Devices Inc. product(s). PLX Devices Inc. does not guarantee 100% accuracy, compatibility and specific application functionality of these documents. Use these documents as guidelines ONLY and refer to your vehicle's service manual for detailed information.

